

## 7.0 napoleon connectivity

# NAPOLEON HOME APP



### HOW DOES IT WORK?

Access your appliance remotely by downloading the **Napoleon Home App** from your app store.

In order to access the app, you will be required to create an account by following the instructions listed within the app (see below for details).

By pairing your appliance to the **Napoleon Home App** via WiFi, you gain control to all modes and functions of the appliance.

All notifications and alarms are sent through the app to keep you connected with ease.



Scan this QR code for direct access to the **Napoleon Home App** website.

### let's get started


#### 1 DOWNLOAD



Download the **Napoleon Home App** from your app store (Google Play or Apple App Store).


**Note:** This requires Android 7.0 or iOS 13.0.

#### 2 REGISTER



Register an account with the **Napoleon Home App** OR sign-in using your Facebook, Google, or Apple account information.

#### 3 CREATE




Enter user information and create a password for the account. Select the country in which the appliance is located.

#### 4 ALMOST THERE



The information entered in Step 3 will be registered to the **Napoleon Home App** and a confirmation will be sent to the email provided.

#### 5 CONFIRM



Open email inbox and select the confirmation link.  
**Note:** The confirmation link must be opened on the device that the **Napoleon Home App** is installed on.

#### 6 RE-CONFIRM



If no email is found, click "Re-Send Confirmation Link" and check junk folder.

## 7.1 adding device

1. Ensure the appliance is plugged in and turned on (**Fig. 1**).
2. Press and hold the FLAME Light Control button on the appliance control panel for 10 seconds (**Fig. 2**).

### note:

The appliance's ember bed indicator will display a green flashing light, and the Wi-Fi icon located on the far left will become illuminated.




Fig. 1

Fig. 2

3. Select "Add Device" and accept permissions (**Fig. 3 & 4**).




Fig. 3




Fig. 4

4. Search for devices and select the device from the list **(Fig. 5 & 6)**.



Fig. 5




Fig. 6

5. Select desired Wi-Fi and connect by entering the Wi-F password of your home **(Fig. 7 & 8)**.
6. Once the appliance has been connected to the access point, it can be given a nickname in order to be more recognizable **(Fig. 9)**.




Fig. 7





Fig. 8



Fig. 9

7.2 using the app

7.2.1 power setting





Power Setting:

Press to turn the appliance On and Off.

The brightness settings are not accessible on this home page when the appliance is turned off. When the appliance is turned on, navigate to the bottom tabs to change fireplace display settings.

7.2.2 heat setting




Heat Setting:

The heat setting can be selected through the heat tab on the appliance home page. The current ambient temperature is displayed on the temperature tab and updated to reflect the target temperature when thermostat mode is selected.


|            |                                                                                                            |
|------------|------------------------------------------------------------------------------------------------------------|
| Off        | No heat.                                                                                                   |
| Fan Only   | Turns on only the fan to circulate air without heat.                                                       |
| On         | Heater is on and operates at full power.                                                                   |
| ECO        | Energy saving mode, heater operates at half power.                                                         |
| Boost      | Increase blower acceleration for 30 minutes with Heater operates at full power.                            |
| Thermostat | Automatically turns the heater ON and OFF to regulate the room temperature to the desired set temperature. |

7.2.3 ember bed setting




**Ember Bed Setting:**  
Select the preferred ember bed colours and brightness settings from the list in the ember bed tab or toggle the auto cycle or pulse brightness function on to cycle through all available colours.

7.2.4 flame setting



**Flame Setting:**  
Control the display of the different flame colours by adjusting the slider for each flame colour. The flame speed can also be adjusted on this page.


## 7.2.5 accessory lights settings



### Accessory Lights Setting:

The weather display brightness can be controlled in the app either on the home page when the appliance is turned off or the lights bottom tab. The side light is also controlled from the lights tab. Bulb warmth selection and brightness can be modified in this section.

## 7.2.6 timer settings



### Timer Settings:

The timer feature can be accessed on the main page. Select from the list of preset times to set a timer that will power off the appliance once the countdown is complete.